




AdvanceProTec



Automatic Tank Filler

(Water, oil, Etc.)

FOR RESIDENTIAL & MODERATE COMMERCIAL USE

SPECIFICATION

Voltage : 0-100 V DC, 100-200 V DC, 200-300 V DC

Usage : Water Tank

Warranty : 1 Year, 2 Years


Material : Plastic,

Frequency : 0-50 , 50-100

Phase : Single Phase, three Phase

Automatic tank filler

1
YEAR
WARRANTY



How Does a Liquid Level Float Switch Work?

Liquid level float switches are used to measure the level of a liquid inside a container. These floats can simply indicate the level of the liquid, or they can hold other functions like turning pumps on or off. How they are made and installed dictate what they will do and how they will work for you!



AdvanceProTec

 advanceprotec.com

CALL OR EMAIL US TODAY

